AutonoVent Installation Instructions

Mounting the unit on a bakkie canopy.

1

Positioning and Marking

The AutonoVent unit is supplied with a paper installation template. Use this template to mark the positions of the six mounting holes and the main opening required for the unit.

Ensure the template is correctly positioned and aligned before marking or cutting the canopy.

2

Cutting the Canopy

Drill the six mounting holes using a standard drill bit. The correct drill bit size is to be confirmed.

Cut the main opening for the vent using a hole saw and an angle grinder, as required.

3

Sealing the Cut Edges

After cutting, seal the exposed edges of the canopy using touch-up paint that matches the canopy's colour. This helps protect the cut edges and maintain a neat finish.

4

Mounting the AutonoVent

The AutonoVent housing has six mounting points and is secured using self-tapping screws that thread directly into the plastic.

A nitrile O-ring runs around the entire housing. As the six mounting screws are tightened, the O-ring compresses against the canopy to create a seal.

Tighten the screws evenly to ensure the unit is securely mounted and the O-ring is properly compressed.

Important note

The correct drill bit size is to be confirmed.